



Do No Harm[®] Ecostrip Pad

Chemical-Free Stripping



Damp stripping or deep scrubbing VCT and Terrazzo floors has never been easier than with the Do No Harm[®] Ecostrip pads from NSS Enterprises. Remove damaged top coats with just water, leaving a surface that is ready for additional finish or burnishing. Ecostrip pads use an abrasive diamond coating to turn the top coat of finish into a slurry which is easily collected by an automatic scrubber. Ecostrip pads can be used with Wrangler and Champ scrubbers and any NSS floor machine.

- Damp strip floors without any chemicals:
 - No odor
 - No splatter on cove base
 - Easy clean up and disposal of stripped finish
- As easy as scrubbing a floor.
- Damp strip without taking an area out of commission.
- For daily scrubbing or burnishing, use the Ecostrip Buff 8500 pad. Available in 20-inch only.
- Ecostrip pads cover about 700,000 square feet before needing replacement. When damp stripping, rinse the pad every 5,000 square feet. Hang the pad to air dry after each use.
- Ecostrip 400 pads available in 13, 14, 15, 16, 17, 18 and 20-inches.

NSS Enterprises, Inc.
3115 Frenchmens Road
Toledo, Ohio 43607-2958
USA
www.nss.com
mailus@nss.com
800-677-1663



Printed on Green Seal[®] certified paper that contains 30% recycled post-consumer fiber.

Do No Harm™ Ecostrip Pad

Application Guide

Benefits

- Damp strip VCT or Terrazzo floors without using chemicals.
- Damp strip with the ease of using an automatic scrubber.
- With no odor, or need to shut down the area, you can damp strip with the Ecostrip pad at any time of day.
- Damp strip up to 5,000 ft²/hr.

Before you start

- Always test the Ecostrip pad in a small out-of-the-way area to ensure the process will work well on your floor.
- Results will vary based on the type of finish, the number of coats applied, and the condition of your finish.
- The Ecostrip pad is intended for use with VCT and Terazzo floors. It is not intended for use with rolled vinyl flooring.
- Do not use the Ecostrip 400 pad without water. This will generate dust.

Using the Ecostrip Pad with your automatic scrubber

1. Dust mop the floor.
2. Install the Ecostrip pad on the pad driver.
3. Set the water flow at about 1/3 of the maximum flow rate.
4. Place the brush motor in the lockdown position.
5. Damp strip the floor by scrubbing at about 25% of the maximum speed. Inspect your results as you go and adjust the speed accordingly.
6. When finished, remove the Ecostrip pad. Rinse the area to remove the slurry of dust by scrubbing with any pad. Water or neutral cleaner can be used.
7. Either apply additional finish, per the manufacturer's recommendation, or burnish the area.

Using the Ecostrip Pad with a floor machine or a high speed corded burnisher

1. Dust mop the floor.
2. Install the Ecostrip pad on the pad drive.
3. Mist the area with a spray bottle filled with water and neutral cleaner. Or use a machine equipped with a tank to dispense water.
4. Damp strip the floor using the floor machine.
5. Dust mop or wet mop to remove residue.
6. Either apply additional finish, per the manufacturer's recommendation, or burnish the area.
7. Burnisher between coats of finish for additional shine.